

Care and Maintenance

Decorative Screen Panels

Decorative Screen Panel Cleaning

- Most dirt can be washed off with a mild soap and water solution.
- Heavier stains can be cleaned with any non-toxic household cleaner.

How Do I Clean My Decorative Screen Panels?

- On occasion, you may want to spray your decorative screen panel with a garden hose. This will remove grass clippings, dirt and fertilizer chemicals and keep it looking as new as possible.
- To remove minor stains, use a non-abrasive liquid cleaner.
- For removal of major stains, try one of the following cleaning agents: *Simple Green, Mr Clean Magic Eraser, Mineral Spirits, Trichloroethylene, *CLR (Calcium, Lime and Rust Cleaner) or vinegar.

Follow the manufacturer's directions.

***Note:** *Goof Off is not recommended to remove stains.*